

Odd-numbered modules installation instructions

When using the SP4 PV optimizer, you may need to install optimizers for an odd number of modules. For example, 17 modules need to be connected to a string.

In the above situation, 16pcs of modules can be used normally with the SP4 PV optimizer, and the 17th module needs to be connected to the SP4 PV optimizer by jumper connection.

That is: **Vin1+/Vin2-** are connected to the modules, and **Vin1-/Vin2+** are short-circuited.

